

echnical Data

Serilelior Crenticels

North Woods



Environmental Health & Sanitation Chemicals

SAFE & FRIENDLY LIQUID CULTURED LIVE BACTERIA

DESCRIPTION

Alive Liquid Bacteria is the answer to eliminating embarrassing urinal and restroom odors. Alive is a liquid suspension of cultured bacteria capable of digesting the most complex proteins, starches, fats, oils, paper, vegetable gums, hair, soaps and kitchen type greases and other organic waste. Ödor Control is provided instantaneously by neutralizing the malodors and eliminating its source. Over 100 Billion nondisease causing bacteria in every quart of ALIVE produce enzymes that degrade these organic wastes naturally leaving only carbon dioxide and water as a result of its digestive action. Because our enzymes are continually regenerated by the massive amount of bacteria, ALIVE is much more economical and efficient than massive doses of enzymes alone. This simply is the most efficient and effective system known to eliminate organic wastes in your environment.

USES / BENEFITS

- **Biodegradable**
- **Non-Toxic**
- **Non-Pathogenic**
- **Eliminates Odors**
- **Digests Organic Waste**
- **Can't Harm Pipes**
- **Excellent For Grease Traps**
- **Maintains All Drains**
- **100 Billion Bacteria Per Quart**
- **Use Safely In Port-A-Toilets**
- **Use Safely In Sump Pumps**
- Eco Logo Certified

Eliminate Urinal Odors NOW!

PRECAUTIONS

Keep Out Of Reach Of Children

SPECIFICATIONS

Color pH	
Acids	None
Toxicity	Non-Toxic
Flash Point	None

Keep In Temperature Range Of 32°F to 110°F

DIRECTIONS FOR USE

FOLLOW INSTRUCTIONS ON CONTAINER COMPLETELY.

Drain Lines: Use Alive at least twice weekly. Use 4oz. in 2" drains, and 8oz. in 4" drains. Always start application on lowest floor level and work up at the rate of one floor level per 24 hour period. Do not treat the same level floor drains twice. When the top level floor is reached, continue the twice weekly treatment from the top level drains only. Grease Traps / Septic Tanks: Consult label directions.

For Carpet, Laundry, Mattresses:

Spray affected surface thoroughly, concentrating on problem area. Allow product dwell time to digest organic solids, approx. 15 minutes. Clean surface using standard procedures.

Hard Surfaces: Spray full strength to problem areas, especially the base of urinals, around toilets, restroom ceramic tile, refuse containers, etc. Allow product to digest solids, approx. 15 minutes. Follow up with a good scrubbing with Sun Drop or Blue Ox High Performance Cleaners.



USE WITH OUR QUICK APPLICATION SYSTEM EXCELLENT FOR PORT-A-TOILETS RECREATIONAL VEHICLES & BOATS ELIMINATES ALL RESTROOM ODORS





800.242.7694 •• www.northwoodstm.com