



# Microfiber Pretreat Instructions

(note: launder mops before using)

1. Fill mix bucket with proper amount of cleaning solutions. Use mix chart guide at the bottom of this page.
2. Place pocket mops microfiber side down in your pretreat bucket. (make sure to place top mop upside down with the microfiber cleaning side facing you).
3. Pour solution over mops.
4. Place lid on pretreat bucket.
5. Flip pretreat bucket over and let sit for 10 minutes.
6. After 10 minutes flip pretreat bucket, remove lid, and install treated mop on pocket frame.

## Mix Chart: (Medium Wetness)

10 mops use 3l (0.75 gals) cleaning solution

15 Mops use 4L (1.0 gals) cleaning solution

20 Mops use 5L (1.30 gals) cleaning solution

25 Mops use 6L (1.60 gals) cleaning solution

For a Wetter Mop add ½ L to any of the above!